

## DYNAFLOW™ Hydraulic Powered Anti-fatigue Insoles


## There are eight DYNAFLOW™ insole size ranges.

REORDER SIZE CHART									
Model	XS	Ø	<b>S2</b>	М	M2		L2	XL	xx
Men		5 to 6.5	7 to 8	7 to 8 Wide	7.5 to 9		9.5 to 10.5	11 to 13.5	14 to 16
Women	5 to 7	7.5 to 8	9 to 10	8.5 to 10 Wide	9 to 10.5		11 to 12		

**DYNA**FLOW™ Insoles will fit in most shoes and boots without trimming however you should make certain that your insoles fit properly. Fold the toe of the insole like a 'taco' and insert it into the shoe with the embossed side down. Check to confirm that the tip of the insole is not jammed against the tip of the toe box.

(Normally trimming the length isn't necessary however you may use sharp scissors to remove segments less than 1/8" thick along the contour of the tip of the insole.)

## You cannot trim the width! Do not cut into the bladder!



The insole is thin enough to accommodate nearly every work shoe and may be used with most orthotics.

